


# Standard Jazz Bass®



**Solder** = location for ground (earth) connections.

Copyright © 2006 Seymour Duncan/Basslines